

HOW TO USE/ADJUST



BREMEN MINI

PORTABLE COFFEE GRINDER | MOULIN À CAFÉ PORTATIF


STEP ONE



Disassemble your grinder by pulling the top chamber from the bottom.

The gears to adjust the grind are found under the top chamber.


STEP TWO



Attach the handle to the top of the grinder.

IMPORTANT: This holds the inner mechanism in place while adjusting the gear.

STEP THREE



While holding the handle in place, twist the gear to adjust the grind.

Counter-clockwise = Coarser

Clockwise = Finer

You should hear a click for each adjustment you make.

STEP FOUR



Reassemble your grinder and you're ready to grind!

DISCLOSURE: Adjusting the grind may take some trial and error to find the grind that suits your needs.